


# Installation Instructions


## 700/700W/G2-700 Wall Guard

**FIG. 1**




Please read all instructions before installing wall guard.

- Cut aluminum retainer to desired length, leaving allowance for end caps, inside corners and outside corners. See Figure 1.



**FIG. 2**




- Drill holes in retainer using 1/4" drill bit in a zigzag pattern. Position retainer on wall allowing for end caps/corners. Level and mark holes. See Figure 2.

NOTE: For concrete or brick wall installation, drill 1/4" holes, 3/8" from each end of retainer for end caps/corners.

NOTE: If using brackets or rubber spacers, use bracket or spacer as a template to mark holes when drilling retainer. See Figures 2a & 2b.

**FIG. 2A**




IPC.357/REV.8


# Installation Instructions

## 700/700W/G2-700 Wall Guard


**FIG. 3**



**FIG. 3A**



**FIG. 4**



3. Drill marked holes on wall using a  $1/4"$  drill bit and position Alligator anchors into holes. Mount retainer on wall and tighten screws to secure. Slide end caps and corners onto the retainer and secure, leaving a  $1/16"$  gap between returns/corners and retainer to allow for adjustment. See Figure 3.

With lengths over 12', a rubber splice is recommended between butt joints for added support. Remove the release paper from the back and press slice in place. See Figure 3a.

NOTE: For concrete or brick wall installation, use #10 x 1  $3/4"$  Phillips pan head screws to secure end caps and corners.

NOTE: If rubber spacers are used, attach them behind the retainer at all mounting hole locations, including those for end caps and corners.

NOTE: If brackets are used, use a  $3/4"$  drill bit for toggle wings or a  $1/2"$  drill bit for lead anchors to drill the marked holes on the wall. Attach end caps and corners with  $5/8"$  hex bolt assembly inserted from the back.

4. Cut the impact bumper to the length between the inside edge of the end caps/corners/splices. Position and snap bumper in place. Cut the cover to length between end caps and/or corners. (Note: Trim factory edges square before installation). Position cover on retainer and adjust returns and/or corners for a tight fit. Push cover over the retainer until it snaps into place. See Figure 4.