

# Instructions for Installation Roof

## Install in temperatures above 40F

1. Clean roof with soap and water. Make sure the substrate membrane is free of dirt and debris. 1a. If applying to a new roof membrane, wipe down the area with mineral spirits. **Don't pour the mineral spirits directly on the roof surface**, pour it into a rag and then wipe down the membrane. This can be done for spots that are very dirty, as well as to make sure XTRM PLY® Treadway® is bonded well to a clean surface. Surface must be dry before moving on to the next step.
2. Lay down the XTRM PLY® Treadway® with the release liner in the place to the area you wish it to be. Once you are happy with the location you can remove the release liner and place the material in that spot. When the adhesive makes contact with the substrate it will be difficult to remove.
3. Use a rubber roller to press the material down on to the surface. This will help to ensure you are bonded well to the substrate.
4. Use XTRM Ply® Universal Sealant around the perimeter of Treadway® to finish the job.

## Instruction for install on steps and other substrates other than roofing

1. Clean surface to be applied to with soap and water. Make sure it is free of dirt and debris. If applying Treadway® to a wood substrate, make sure all loose particles have been blown or vacuumed off the area you would like to apply it to.
2. Make sure surface is completely dry.
3. Lay down the XTRM PLY® Treadway® with the release liner in the place to the area you wish it to be. Trim to size if need be.(material cuts easy with utility knife) Once you are happy with the location, you can remove the release liner and place the material in that spot. When the adhesive makes contact with the substrate it will be difficult to remove.
4. Use a rubber roller to press the material down on to the surface. This will help to ensure you are bonded well to the substrate.

**WARNING:** XTRM PLY® TREADWAY® adhesive layer is very aggressive. Once it is bonded to an RV Roof membrane it is a permanent part of the roof. Do not try and remove it as it could take off the roof membrane underneath with it.