## Installation Instructions

construction adhesive you are using.

- Mounting Option 1: use construction adhesive to mount plain back moldings For best adhesion, wall should be clean and free of oil, moisture and dust and should be approximately 60 degrees Fahrenheit. A hair dryer may be used to warm up wall surface if
  - needed. We recommend using Liquid Nails® Polyurethane formulation to mount metal moldings onto
  - drywall Apply an appx 1/4" diameter bead of construction adhesive on the back side of the molding in the "S" pattern shown below. Adhere to wall. Follow remaining instructions listed on the