


Anti-Slip Hi-Traction™ INSTALLATION DIAGRAMS

(Walkway Covers)

Walkway Cover Installation with Mechanical Fasteners

(See back for adhesive instructions)


Walkway Cover Installation Over Grating




Walkway Cover Installation Over Diamond/Checker Plate



Walkway Cover Installation Over Concrete



Walkway Cover Installation Over Wood



Please refer to the Installation guidelines literature for detailed "step-by-step" written instructions.

NOTE: Please reference red "Attention" instructions on back of this page for air tool usage and instructions.

recommends placing mechanical fasteners 1" x 1" in each corner of your Anti-Slip Cover with spacing 10" to 14" between each fastener.

* The number of Saddle Clip Assemblies is directly influenced by the condition of the grating to be covered. New and good condition grating may not require as many Saddle Clip Assemblies.

† Good condition is considered flat/level and non-corroded. Contact Safeguard to discuss your application.

Anti-Slip Hi-Traction™ INSTALLATION & CLEANING

Covers Easy retrofit installation and cleaning guide

Installation.

Covers are non-load bearing, and are pre-fabricated for quick and easy installation over existing substrates including Concrete, Metal, Fiberglass, Steel & Composite Grating, Wood, and Tile. Depending on the base material of construction and surface to be covered, mechanical fasteners, urethane adhesive, PSA (pressure sensitive adhesive) and tack-welding can be used. Pre-drilled holes are available to aid in the process.

Refer to Safeguard Technology's detailed Installation Guide and Diagrams for step-by-step instruction.

Quick Reference Installation Guide

	Mechanical Fasteners	Adhesive	PSA (Pressure Sensitive Adhesive)	Tack-Welding
Pultruded FRP Step Covers & Walkway Covers	X	X		
1mm FRP Walkway Covers	X	X	X	
* Weld-Tab Walkway Covers Are available for tack-welding				X
Pultruded FRP Ladder Rung Covers (Hollow rungs only)	X	X		
Stainless & Galvanized Steel Step & Walkway Covers	X	X		X
Stainless & Galvanized Steel Ladder Rung Covers				X
Flexible PVC Vinyl Walkway Covers		X	X	
Fiberglass Pipe & Cable Covers	X	X		

Cleaning.

Regular cleaning will keep your Hi-Traction™ Covers free of debris and looking new. Most household or industrial methods can be used. Detergents and mild degreasers work well. For stubborn deposits, use a stiff bristle brush. High pressure heated water (as used in food processing plants) may be used in industrial environments.

CAUTION: Do not use mops. The gritted surface will catch and retain fibers. Solvents are not generally recommended. If necessary, mild solvents may be used provided they are diluted and immediately hosed off with water.



Example showing before and after pressure washing

Snow and Ice Removal.

1. Brooms will remove loose snow.
2. Plastic shovels are suitable for top layers of heavy snow accumulation. Do not use metal shovels, scrapers, or wire brushes.
3. Use salt, calcium chloride or other melting agents on compacted snow and ice.

Top Coat.

If you choose to apply a top coat of paint to revitalize the color after years of wear, only apply a thin coating of alkyd silicone enamel. A heavy application will diminish the effectiveness of the grit surface, and reduce coefficient of friction values.



