


Installation Diagrams

Safety Underfoot

Walkway Cover Installation Over Diamond/Checker Metal Plate, Concrete or Wood



Vinyl Walkway Cover Installation



Peel release liner and press firmly in place



SAFEGUARD TECHNOLOGY INC.

1.440.247.1695 Phone
 1.800.989.1695 Toll-Free in the U.S. and Canada
 email: info@safeguard-technology.com
www.safeguard-technology.com